



# 15 kN BOTTOM PLATE FIXING

## ▶ SCREW BOLT BLUE HEX HEAD

M10 x 140mm

M10 x 150mm (Frame Packer)

M10 x 200mm (Double Bottom Plate)

Mechanical Galvanised

### BONUS<sup>+</sup> IN EACH TUB.

Includes  
Square washer,  
Impact Socket  
& SDS Drill Bit

(\*Excluded M10 x 200mm)



## ▶ Installation Guide

**Step 1**  
Using the correct masonry drill bit, drill a hole to the required embedment +10mm. Ensure that the minimum edge distance of 55mm is adhered to.

**Step 2**  
Clean dust and debris from hole.

**Step 3**  
Screw in anchor using torque wrench or impact wrench until flange head is firmly secured against washer. **DO NOT OVER-TIGHTEN.**

