



BOTTOM PLATE FIXING

▶ **SCREW BOLT
GREEN HEX HEAD
M8 x 100mm**
3kN Internal frame



▶ **SCREW BOLT
RED HEX HEAD
M8 x 140mm**
7kN External frame



▶ **THROUGH BOLT
M12 x 135mm**
7kN External frame



**SCREW BOLT
BLUE HEX HEAD**

▶ **M10 x 140mm**
15kN Bottom plate fixing

▶ **M10 x 150mm**
15kN Bottom plate fixing
Frame packer

▶ **M10 x 200mm**
15kN Bottom plate fixing
Double bottom plate



▶ Installation Guide

Step 1
Using the correct masonry drill bit, drill a hole to the required embedment +10mm. Ensure that the minimum edge distance of 55mm is adhered to.

Step 2
Clean dust and debris from hole.

Step 3
Screw in anchor using torque wrench or impact wrench until flange head is firmly secured against washer. **DO NOT OVER-TIGHTEN.**